



New Stormwater Requirements

Effective July 28, 2016

Compliance is important not only to protect the Waters of the US but also to avoid federal, state and city penalties. Federal penalties include prison and fines up to \$37,500 per day per violation. Whenever possible the City encourages using the Right of Way (ROW)* as a vegetated buffer between construction activities and the street or alley. If the ROW must be disturbed for construction or storage of materials then the following requirements apply:

1. At the end of each work day, the street shall be free of pollutants originating from the construction site.
2. No loose material may be placed or stored in ROW without sufficient controls installed and maintained to prevent any discharge to pavement or other drainage conveyance. Streets and alleys may not be used for material storage.
3. Inlet protection must not:
 - a. Impede the flow of water. Any device that covers a portion of the face of an inlet will impede the flow of water.
 - b. Impede the flow of traffic.
 - c. Create siltation on pavement.
4. This placard is posted in a visible location on site.

* ROW is that portion of the street and parkway which is owned by an agency or association such as the City, State, County or HOA. In most residential areas it extends 9 feet beyond the curb.

For more information go to <http://www.friscotexas.gov/490/Stormwater>

NUEVOS REQUISITOS DE AGUAS PLUVIALES

Efectivo a partir de Julio 28 de 2016.

El cumplimiento de la leyes es importante tanto para proteger las aguas de los EUA, como para evitar penalidades o multas federales, estatales y municipales. Penas o multas federales podrian llegar a ser hasta \$37,500.00 dolares por dia y por cada violacion, o incluir hasta la carcel. Siempre que sea possible, la Ciudad anima a utilizar el derecho de paso como una area protegida o zona neutral entre las actividades de construccion ya sea la calle o el callejon. Si el area de derecho de paso tuviera que ser usada para construccion o almacenamiento de materiales, se aplicaran los siguientes requerimientos:

1. Al final de cada dia de trabajo, la calle debera estar libre de contaminantes procedentes de la obra.
2. NINGUN material suelto puede ser colocado o almacenado en el area del derecho de paso, sin suficientes controles preventivos instalados y mantenidos para evitar cualquier derramamiento al pavimento asi como otros desperdicios que entren al drenaje. Las calles ni los callejones deben ser usado como almacenamiento de material.
3. La proteccion de la ranura NO DEBE:
 - a. Impedir el flujo del agua. No debe haber ningun dispositivo, o desperdicio que cubriera la ranura del drenaje que evitara el flujo del agua.
 - b. Impedir el flujo del trafico.
 - c. Crear sedimentacion sobre el pavimento.
4. Este anuncio debe ser publicado en un lugar visible en el sitio.

* Derecho de paso es parte de la calle asi como el borde de la banqueta son propiedad publica, propiedad de un organismo o una asociacion como la Ciudad, Estado, Condado o HOA. En la mayoría de las zonas residenciales se extiende a 9 pies mas alla de la acera.